

1. Menü Grundeinstellungen

Programmierbare Nutzeridentifikationsnummer
(User ID)

Im Menü Grundeinstellungen (Setup Mode) erreichen Sie den Unterpunkt SET USER ID. Nach Drücken der Wiedergabetaste wird die aktuelle ID angezeigt. Falls noch keine ID eingetragen wurde, steht die ID Nummer auf Null (000000 00). Mit der Vorlauf- oder Rücklaftaste wählen Sie die entsprechende Position aus und mit der Wiedergabe - oder Umschalttaste verändern Sie den Wert. Das Menü „Set User Id“ verlassen Sie durch Drücken der Aufnahmetaste. Die Identifikationsnummer wird abgespeichert und auf der CF Karte in der Datei USERID.txt eingetragen. Nach der Übertragung Ihrer Dateien auf den Computer können Sie sich den Inhalt der Datei USERID.txt mit einem Textprogramm ansehen.

2. Dauerfunktion für Vor - oder Rücklauf

Drücken Sie die Vorlauf- oder Rücklaftaste im Aufnahme-Modus nur kurz (< 1 sec), dann wird der Vor- oder Rücklauf in Dauerfunktion geschaltet. Sie können mit der Vor- oder Rücklaftaste die Laufrichtung ändern. Durch Drücken einer beliebigen anderen Taste wird die Dauerfunktion abgebrochen. Falls das Gerät sich vorher im Rücklauf oder in der Wiedergabe befand, wird automatisch in die Wiedergabe geschaltet.

3. Scan-Funktion

Die Wiedergabezeit der Scan-Funktion wurde auf 5 sec. verkürzt.

SM-911 (04/0011)

1. Menu Basic Settings

In the Menu Basic Settings (Setup Mode) you will find the new subroutine SET USER ID. Pressing the "Play/Stop" button the current User ID will be shown. If there is no ID Number present "000000 00" will be displayed. Pressing the "Rewind" or "Forward" button you select the position of the digit to be altered and changed by using the "Shift" or "Play/Stop" button. The User ID will be stored in the CF-Card in the "userid.txt" file and you can leave the Menu "Set User Id" by pressing the "Rec" button. After having carried over your files to your PC the contents of the file will be shown under USERID.txt using a "Word" software.

2. Run Out Winding Function

Pressing the "Forward" or "Rewind" button for less than a second in the Record Mode results in a "Run Out Function" in fast forward or rewind Mode. You may change the direction by using the "Forward/Rewind" button. Pressing any button will stop the "Run Out Function". Having set the machine previously in Fast Forward or Rewind Mode will result in setting the machine into Playback Mode automatically.

3. Scan-Function

Play back of dictation in "Scan-function" has been reduced to 5 seconds.